





Device Design

- 3 Fabrication Steps:
- A) Pads - red
 - B) Manhattan JJ - purple
 - C) Patches - green


20 identical Devices each Chip (7mm x 7mm) - 300nm electrode width



SEM Inspection of the device



This figure is rotate 90 deg wrt the previous one




Here is a recipe only to produce cross-type Josphehon Junctions using two stacked resists (and a single exposure)


Pads

Operation	Description	Tool	Comment	Inspection
Clean	1,3 Dioxilane - 10 min			
	Acetone –5 min			
	IPA -1 min			
Pre-Bake	185C – 120s			
Spin	PMMA A4 spin (vent hole closed) 90 s@4.0krpm, (film ≈ 300 nm)			
Bake	120 s bake, 185 · C			
Expose	Base dose 1000 $\frac{\mu\text{C}}{\text{cm}^2}$	10nA		
Ash	45 s			
Develop	MIBK: IPA 1: 3 – 60s + IPA 10 s			
Evaporate	$\theta = 0 , 1.0 \text{ A/s}, 100\text{nm}$			
Lift Off	Acetone Overnight (or 3 h)			

Junctions

Operation	Description	Tool	Comment	Inspection
Clean	1,3 Dioxilane - 10 min			
	Acetone –5 min			
	IPA -1 min			
Pre-Bake	185C – 120s			
Spin	MMA EL 13 spin (vent hole closed) 90 s@5.0krpm, (film ≈ 350 nm)			
Bake	90 s bake, 185 · C			
Spin	CSAR 960 s@2.0krpm (film ≈ 300 nm)			
Bake	90 s bake 185 · C			
Expose	Base dose –825 $\mu\text{C}/\text{cm}^2$	1nA		



Develop	n-Amyl- 60s + IPA 15 s; then MIBK: IPA 1: 3 – 75s + IPA 15 s	Ash 30 s at the End		
Evaporate	$\theta = 42,1.6 \text{ A/s}$, 45 nm			
Evaporate	$\theta = 42,1.6 \text{ A/s}$, 65 nm			
Lift Off	Acetone Overnight (or 3 h)			

Patches

Operation	Description	Tool	Comment	Inspection					
Clean	1,3 Dioxilane - 10 min								
	Acetone – 5 min								
	IPA -1 min								
Pre-Bake	185C – 120s								
Spin	PMMA A4 spin (vent hole closed) 60 s@4.0krpm, (film \approx 300 nm)								
Bake	120 s bake 185 · C								
Expose	Base dose 1000 $\mu\text{C}/\text{cm}^2$	3nA							
Ash	45 s								
Develop	MIBK: IPA 1: 3 – 60s + IPA 10 s								
Mill	<table><tr><td>500V</td><td>27mA</td><td>Acc V= 90</td><td>T= 3.30min</td><td>Tilt =30</td></tr></table>	500V	27mA	Acc V= 90	T= 3.30min	Tilt =30			
500V	27mA	Acc V= 90	T= 3.30min	Tilt =30					
Evaporate	$\theta = 0, \frac{1.0 \text{ A}}{\text{s}}$, 140nm								
Lift Off	Acetone Overnight (or 3 h)								